

DS 3408 Programming Instructions

Parameters on the imager are set by scanning the following three bar codes, in order. There will be a double-beep after each scan, if the scan was successful.

Step #1 – Set Defaults



Step # 2 – HID Keyboard Emulation



Step #3 – Data Matrix Inverse Autodetect (not required for QCTS, but after defaults are set, this must be scanned to allow the imager to read white on black data matrix symbols)

